CUSTOM


Wood Blinds REAL WOOD | FAUX WOOD


TECHNICAL GUIDE

VOLOR

23-0009-070

How To Measure Quickly and Accurately





INSIDE MOUNT (IM) INSTALLATION — For a beautiful framed look

1 MEASURE WIDTH

Measure to the nearest 1/8 in. between inside surfaces of window frame; at the top, middle, and bottom.

Record the narrowest width of the three.

MEASURE HEIGHT

Measure to the nearest $\frac{1}{18}$ in. from inside surface at top of window to top of sill; at the left, middle, and right.

Record the tallest height of the three.

3 MEASURE DEPTH

Measure exact depth of window casing making note of any obstacles, i.e. handles, tracks, or cranks that could interfere with the blind function.

Use the shortest depth.

OUTSIDE MOUNT (OM) INSTALLATION — For increased light control and privacy

1 MEASURE WIDTH

Measure to the nearest $\frac{1}{8}$ in. between outermost points where blind is to be placed. Measurement should overlap each side of window frame by at least $1\frac{1}{2}$ in.

2 MEASURE HEIGHT

Measure to the nearest $\frac{1}{8}$ in. from where top of blind will be located to top of sill, or measure to point of blind reach if no sill.

HELPFUL HINTS

Always use a metal tape measure as cloth may stretch

Measure your window – not your existing blind or shade

Measure each window separately even if they appear to be identical

Check depth to ensure blind will clear any obstacles and can accommodate headrail if flush mount is desired


If you prefer blind not to touch sill, deduct 1/4"

If there is no sill, measure height to point where blind is to reach

NOTE: Take all measurements to the nearest ½ in. **DO NOT** take any deductions. The factory will make the necessary adjustments to help ensure your window covering operates smoothly.

Visit www.levolor.com/how-to-measure for more measuring information

Window and Measuring Terminology



WINDOW COMPONENTS TERMINOLOGY

 Collectively, the sill and jambs are called the "window casement" or "frame."




INSIDE MOUNT

- Blind fits within window opening
- Great for windows with beautiful trim.



OUTSIDE MOUNT

- Blind mounts outside window opening.
- Increased light control and privacy.



MULTIPLE BLINDS ON ONE HEADRAIL

- Provides the clean appearance of a single blind with the ability to operate each blind independently.
- Can be mounted inside or outside.
- Can be 2-on-1 or 3-on-1, depending on width of window. 2-on-1 is shown in the image above.

How to Measure Two Blinds on One Headrail

INSIDE MOUNT (IM) INSTALLATION — For a beautiful framed look

1 MEASURE WIDTH

Total Blind Width — Measure to the nearest ½ in. between inside surfaces of window frame; at the top, middle, and bottom. **Record the narrowest width of the three.**

Left Blind Width — Measure the width that you want the left blind to cover. **Order this blind first when placing your order.**

Right Blind Width — Measure the width that you want the right blind to cover.

2 MEASURE HEIGHT

Overall Blind Height — Measure to the nearest ½ in. from inside surface at top of window to top of sill; at the left, middle and right. **Record the tallest height of the three.**

3 MEASURE DEPTH

Measure exact depth of window casing making note of any obstacles, i.e. handles, tracks, or cranks that could interfere with the blind function. **Use the shortest depth.**

OUTSIDE MOUNT (OM) INSTALLATION — For increased light control and privacy

1 MEASURE WIDTH

Overall Blind Width — Measure to the nearest ½ in. between outermost points where blind is to be placed. Add an additional 3 in. to 6 in. to total width for maximum privacy. Left Blind Width — Measure the width that you want the left blind to cover. Order this blind first when placing your order.

Right Blind Width — Measure the width that you want the right blind to cover.

MEASURE HEIGHT

2 Overall Blind Height — Measure to the nearest 1/8 in. from where top of blind will be located to top of sill, or measure to point of blind reach if no sill.

How to Measure Three Blinds on One Headrail

INSIDE MOUNT (IM) INSTALLATION — For a beautiful framed look

MEASURE WIDTH

Total Blind Width — Measure to the nearest ½ in. between inside surfaces of window frame; at the top, middle, and bottom. **Record the narrowest width of the three.**

Left Blind Width — Measure the width that you want the left blind to cover. **Order this blind first when placing your order.**

Middle Blind Width — Measure the width that you want the middle blind to cover.

Right Blind Width — Measure the width that you want the right blind to cover.

2 MEASURE HEIGHT

Overall Blind Height — Measure to the nearest ½ in. from inside surface at top of window to top of sill; at the left, middle, and right. Record the tallest height of the three.

3 MEASURE DEPTH

Measure exact depth of window casing making note of any obstacles, i.e. handles, tracks, or cranks that could interfere with the blind function. Use the shortest depth.

OUTSIDE MOUNT (OM) INSTALLATION — For increased light control and privacy

MEASURE WIDTH

Overall Blind Width — Measure to the nearest 1/8 in. between outermost points where blind is to be placed. Add an additional 3 in. to 6 in. to total width for maximum privacy.


Left Blind Width — Measure the width that you want the left blind to cover. Order this blind first when placing your order.

Middle Blind Width — Measure the width that you want the middle blind to cover.

Right Blind Width — Measure the width that you want the right blind to cover.

MEASURE HEIGHT

Overall Blind Height — Measure to the nearest 1/8 in. from where top of blind will be located to top of sill, or measure to point of blind reach if no sill.



Total Blind Width

Middle Blind Width Right - Blind Width —

Height

Left - Blind Width

Product Specifications

Use technical information listed below to assist in product selection.

| Product Performance Comparison | | | | | | |
|--------------------------------|-------------------------------|----------------------------|-------------------------------------|--|--|--|
| Category | Resistance to Slat Warpage | Resistance to UV Fading | Lift Weight* (Approx. 36" x 60") | | | |
| Real Wood | Better | Best | Best (5 lbs) | | | |
| Faux Wood | Best | Better | Better (8.5 lbs) | | | |

^{*} Weight of slats and bottom rail only. This weight does not include valance, headrail, or componentry weight as these are stationary when blind is raised/lowered.

Note: Not applicable to Classic Value Faux Wood.

Number of Cords Comparison:

| Levolor Real Wood | Levolor Faux Wood | Other Faux Wood |
|----------------------|----------------------|----------------------|
| 2.6 avg ladder cords | 3.7 avg ladder cords | 4.5 avg ladder cords |

Note: Not applicable to Classic Value Faux Wood.

LEVOLOR Custom Faux Wood uses nearly 1 less ladder per blind than the competition

Benefits of Fewer Cords:

- Cleaner look that allows the beauty of the slat finishes to be the spotlight
- Less obstructed view of the outdoors
- Improved safety

| Light Control Performance Comparison | | | | | | |
|---|---|---|--|--|--|--|
| Route, Operating System Prior Light Blocking Improved Light Performance Blocking Performa | | | | | | |
| Privacy | 2 | 3 | | | | |
| Standard Route | 1 | 3 | | | | |

Index (Percent Light Blockage): 1 = < 70%, 2 = 70-80%, 3 = 80-90%

Blinds will not block out 100% of light or achieve complete darkness. Small percentages of light may still pass through slat gaps and/or route holes.

Note: Not applicable to Classic Value Faux Wood.



| Stacking Chart – Height Includes Headrail | | | | | | | | | | | | |
|---|--------|--------|--------|--------|--------|-----|--------|--------|--------|--------|--------|---------|
| Blind Height | 24" | 36" | 42" | 48" | 54" | 60" | 66" | 72" | 84" | 96" | 108" | 120" |
| 2" Slats | 4 1/2" | 5 1/4" | 5 3/4" | 6 1/4" | 6 1/2" | 7" | 7 1/4" | 7 ½" | 8 1/4" | 9" | 9 3/4" | 10 3/4" |
| 2" Slats-Classic Value Only | 3 3/4" | 4 5/8" | 5" | 5 1/4" | 5 3/4" | 6" | 6 1/2" | 6 3/4" | 7 1/2" | N/A | N/A | N/A |
| 2 ½" Slats | 4 1/4" | 4 3/4" | 5 1/4" | 5 1/2" | 5 3/4" | 6" | 6 1/4" | 6 3/4" | 6 1/2" | 7 3/4" | 8 1/2" | 9" |

| Ladder Spacing | | | | | | | |
|----------------|----------------------|-------------------|----------------------|------------------|----------------------|--|--|
| Classic Valu | e Blinds | Faux Wood | Blinds | Real Wood Blinds | | | |
| Blind Width* | Number of Ladders | Blind Width* | Number of Ladders | Blind Width* | Number of Ladders | | |
| 18"- 24" | 2 | 7 1/4" - 21 1/2" | 2 | 6" - 36" | 2 | | |
| 24 1/8"-36" | 3 | 24 5/8" - 36" | 3 | 36 - 54" | 3 | | |
| 36 1/8" - 48" | 4 | 36 1/8" - 50 1/2" | 4 | 54" - 60" | 3 | | |
| 48 1/8" - 54" | 5 | 50 %" - 65" | 5 | 60" - 84" | 4 | | |
| 54 1/8" - 60" | 5, 6 [†] | 65" - 79 ½" | 6 | 84" - 96" | 5 | | |
| 60 ½ - 66" | 5 [†] , 6 | 79 %" - 94" | 7 | | | | |
| 66 1/8" - 72" | 6 | 94 1/8 - 96" | 8 | | | | |
| 72 1/8" - 78" | 6 [†] , 7 | | | | | | |
| 78 1/8" - 84" | 7, 8 [†] | | | | | | |
| 84 1/8" - 96" | 8 | | | | | | |

^{*}Refer to Standard Factory Adjustments from Ordered Width Table †For Classic Value Faux Wood in Light Gray, Pecan, and Walnut Only

Critical Dimensions


To ensure your window covering selection is available and will fit properly, refer to critical dimension information below.


| Standard Factory Adjustments from Ordered Width | | | | | | |
|---|-------|-------|--|--|--|--|
| DO NOT make any deductions to your measurements | | | | | | |
| Inside Mount Outside Mount | | | | | | |
| Headrail | -1/2" | -1/2" | | | | |
| Blind Width | -1/2" | 0" | | | | |
| Valance | -1/8" | +1" | | | | |

| Headrail and Bottom Rail Dimensions (inches) | | | | | | |
|--|--------|--------|-------------|--------|--|--|
| Operating System | Hea | drail | Bottom Rail | | | |
| Operating System | Height | Depth | Height | Depth | | |
| 2" and 2 1/2" Blind | 1 1/2" | 2 1/4" | 11/8" | 2 1/4" | | |
| 2" Classic Value Only | 1 1/2" | 2 3/8" | 3/4" | 2" | | |

| Installation Brackets | | | | | | |
|-----------------------|--------------|-----------------------|----------------------|--|--|--|
| | End Brackets | ets Support Brackets* | | | | |
| Blind Width | All Blinds | Classic Value | Real Wood, Faux Wood | | | |
| Below 30" | 2 | 0 | 0 | | | |
| 30" - 48" | 2 | 1 | 0 | | | |
| 38 1/8" - 72" | 2 | 2 | 1 | | | |
| 72 1/8" - 84" | 2 | 3 | 1 | | | |
| 84 1/8" - 96" | 2 | 4 | 2 | | | |
| 96" - 144" | 2 | N/A | 3 | | | |

^{*}Support brackets are evenly spaced along length of headrail






| Standard Valance Return Dimensions — Outside Mount | | | | | | |
|--|--------|--------|--|--|--|--|
| Blind Size Cordless Lift No Lift | | | | | | |
| 2" Blind | 3 1/8" | 2 1/8" | | | | |
| 2" Blind - Classic Value Only | 3" | N/A | | | | |
| 2½" Blind | 3 ½" | 3 ½" | | | | |






Headrail Flush See "Y" measurement in chart



Valance Flush See "Z" measurement in chart





| Mounting Depth | | | | | | | |
|---------------------------------|----------|--------|--------------------------|-----------|-----------|--|--|
| | | | Minimum Mounting Surface | | | | |
| Slat Size | Headrail | | Headrail | Headrail | Valance | | |
| Siat Size | Height | Depth | Protrudes (X) | Flush (Y) | Flush (Z) | | |
| 2" Slat | 1 1/2" | 2 1/4" | 3/4" | 2 ½" | 3 1/2" | | |
| 2" Slat - Classic Value Only | 1 1/2" | 2 3/8" | 3/4" | 2 ½" | 3 ½" | | |
| 2 1/2" Slat | 1½" | 2 1/4" | 1 1/4" | 3" | 3 1/8"† | | |

Headrail Protrudes – clearances necessary for either side, back, or top mount $^\dagger \, \text{With spacer}$

VALANCE RETURN DIMENSIONS - INSIDE MOUNT

- For inside mount installations where headrail protrudes from window casing.
- Returns may be ordered in sizes ranging from 1/2" to 6".
- Measure to the nearest 1/8" using a metal tape measure.
- If the valance is the same width as the blind, measure from the window trim to the end of the headrail.
- If the valance is wider than the blind and extends over the window trim, measure from the wall to the end of the headrail.

(If you are unable to measure for returns, LEVOLOR recommends a return size of ½" which will work for most situations.)

Critical Dimensions

Minimum / Maximum dimensions for Blind configurations

| Single Blind Minimum and Maximum Limitations | | | | | | |
|--|------------------|---|-------------------|-------------------|--|--|
| 2" Real Wood | Minimum Width | Maximum Width | Minimum Height | Maximum Height | | |
| Center Tilt, No Lift Control | 9" | 12 7/8" | 8" | 120" | | |
| No Tilt or Lift Control | 7 1/4" | 8 1/8" | 8" | 120" | | |
| Cordless Standard Slat | 13" | 96" | 10" | 84" | | |
| Cordless Privacy Slat | 18 1/8" | 96" | 10" | 84" | | |
| Motorization | 23" | 96" | 10" | 84" | | |
| 2 ½" Real Wood | Minimum Width | Maximum Width | Minimum Height | Maximum Height | | |
| Center Tilt, No Lift Control | 9" | 12 7/8" | 8" | 120" | | |
| No Tilt or Lift Control | 7 1/4" | 8 1/8" | 8" | 120" | | |
| Cordless - Standard Slat | 13" | 84" | 10" | 84" | | |
| Cordless - Privacy Slat | 18 1/8" | 84" | 10" | 84" | | |
| Motorization | 23" | 84" | 10" | 84" | | |
| 2" Faux Wood | Minimum Width | Maximum Width | Minimum Height | Maximum Height | | |
| Center Tilt, No Lift Control | 9" | 12 7/8" | 8" | 120" | | |
| No Tilt or Lift Control | 7 1/4" | 8 1/8" | 8" | 120" | | |
| Cordless Standard Slat | 13" | 96" | 10" | 84" | | |
| Cordless Privacy Slat | 18 1/8" | 96" | 10" | 84" | | |
| Motorization | 23" | 96" | 10" | 84" | | |
| Classic Value [†] | 18" | 96" | 24" | 84" | | |
| 2 ½" Faux Wood | Minimum Width | Maximum Width | Minimum Height | Maximum Height | | |
| | | | | | | |
| Center Tilt, No Lift Control | 9" | 12 ⁷ /8" | 8" | 120" | | |
| Center Tilt, No Lift Control No Tilt or Lift Control | | 12 ⁷ / ₈ " 8 ⁷ / ₈ " | 8" 8" | 120" 120" | | |
| | 9" | | _ | | | |
| No Tilt or Lift Control | 9" 7 ½" | 8 1/8" | 8" | 120" | | |

| 2-on-1 Blind Minimum and Maximum Limitations | | | | | | | |
|--|------------------|------------------|-------------------|-------------------|--|--|--|
| 2" Real Wood | Minimum Width | Maximum Width | Minimum Height | Maximum Height | | | |
| Cordless Standard Slat | 36 1/2" | 144" | 10" | 84" | | | |
| Cordless Privacy Slat | 37 3/4" | 144" | 10" | 84" | | | |
| Motorization | 47" | 96" | 10" | 84" | | | |
| 2 ½" Real Wood | Minimum Width | Maximum Width | Minimum Height | Maximum Height | | | |
| Cordless Standard Slat | 36 1/2" | 144" | 10" | 84" | | | |
| Cordless Privacy Slat | 37 3/4" | 144" | 10" | 84" | | | |
| Motorization | 47" | 96" | 10" | 84" | | | |
| 2" Faux Wood | Minimum Width | Maximum Width | Minimum Height | Maximum Height | | | |
| Cordless Standard Slat | 36 ½" | 144" | 10" | 84" | | | |
| Cordless Privacy Slat | 37 3/4" | 144" | 10" | 84" | | | |
| Motorization | 47" | 96" | 10" | 84" | | | |
| Classic Value | N/A | N/A | N/A | N/A | | | |
| 2 ½" Faux Wood | Minimum Width | Maximum Width | Minimum Height | Maximum Height | | | |
| Cordless - Standard Slat | 36 1/2" | 144" | 10" | 84" | | | |
| Cordless - Privacy Slat | 37 3/4" | 144" | 10" | 84" | | | |
| Motorization | 47" | 96" | 10" | 84" | | | |

2-on-1 blinds with Motorization will feature a single tilt motor. Both blinds will tilt from the same motor and shaft.

| 3-on-1 Blind Minimum and Maximum Limitations | | | | |
|--|---------------------|------------------|-------------------|-------------------|
| 2" Real Wood | Minimum Width | Maximum Width | Minimum Height | Maximum Height |
| Cordless Standard Slat | 55" | 144" | 10" | 84" |
| Cordless Privacy Slat | 56 ⁷ /8" | 144" | 10" | 84" |
| Motorization | N/A | N/A | N/A | N/A |
| 2 ½" Real Wood | Minimum Width | Maximum Width | Minimum Height | Maximum Height |
| Cordless Standard Slat | 55" | 144" | 10" | 84" |
| Cordless Privacy Slat | 56 7/8" | 144" | 10" | 84" |
| Motorization | N/A | N/A | N/A | N/A |
| 2" Faux Wood | Minimum Width | Maximum Width | Minimum Height | Maximum Height |
| Cordless Standard Slat | 55" | 144" | 10" | 84" |
| Cordless Privacy Slat | 56 ⁷ /8" | 144" | 10" | 84" |
| Motorization | N/A | N/A | N/A | N/A |
| Classic Value | N/A | N/A | N/A | N/A |
| 2 ½" Faux Wood | Minimum Width | Maximum Width | Minimum Height | Maximum Height |
| Cordless Standard Slat | 55" | 144" | 10" | 84" |
| Cordless Privacy Slat | 56 7/8" | 144" | 10" | 84" |
| Motorization | N/A | N/A | N/A | N/A |

*All 2-on-1 and 3-on-1 Minimum widths are Inside Mount measurements

| Motorized Maximum Square Feet | | | |
|--------------------------------|----------------|--|--|
| 2" Real Wood | 50 square feet | | |
| 2 ½" Real Wood 45 square feet | | | |
| 2" Faux Wood 45 square feet | | | |
| 2 ½" Faux Wood 36 square feet | | | |
| 2" Faux Wood Classic Value N/A | | | |

For additional product information visit LEVOLOR.com/woodblinds

^{*}See price grids for exact limitations
† Classic Value Blinds are built with a height tolerance, therefore extra slats may rest on the bottom rail.

Note: Maximum height for blinds 132"-144" wide is 108"
All 3-on-1 blinds must be Cordless.
All 2-on-1 and 3-on-1 Minimum widths are Inside Mount measurements.

^{*}See price grids for exact limitations

REAL AND FAUX WOOD PRODUCT DETAILS AND FINISH INDEX

REAL WOOD PRODUCT DETAILS

- Premium hardwood delivers a beautiful finish and exceptional light control.
- Rich, natural wood enhances your style while protecting flooring and furniture from fading.
- Available in 2" and 2 1/2" slats.
- The natural characteristics of wood provide for uniquely beautiful blinds.
- Variations in color and grain are inherent to real wood, thus slats may be slightly darker or lighter than shown in the sample books.
- Variations in color in no way compromise the quality of the blinds.

| Real W | ood Finish Index | | |
|------------------------|------------------|---------------|--|
| Finish Name | 2" Real Wood | 2½" Real Wood | |
| Almost White | 12002321 | 12502321 | |
| American Walnut | 120DS005 | N/A | |
| Brandy | 12081338 | 12581338 | |
| Bright White* | 120WH056 | N/A | |
| Chalk Gray | 120GY048 | N/A | |
| Chenille | 12078027 | N/A | |
| Cherry | 120MS001 | N/A | |
| Chestnut | 12002777 | 12502777 | |
| Cinnamon | 12081341 | 12581341 | |
| Colonial Mahogany | 120DS003 | 125DS003 | |
| Colonial Pine | 12078082 | 12578082 | |
| Dover | 12081019 | 12581019 | |
| English Walnut | 12002772 | N/A | |
| Espresso | 120DS001 | 125DS001 | |
| Estate Autumn | 12002897 | N/A | |
| Estate Gray | 120GY047 | N/A | |
| Estate Oak | 12002888 | N/A | |
| French Roast | 12081340 | N/A | |
| Golden Oak | 12002771 | 12502771 | |
| Harvest Oak | 120MS006 | N/A | |
| Hickory | 12078097 | N/A | |
| High Gloss Golden Oak | 12002352 | N/A | |
| Maple | 120LS006 | N/A | |
| Matte Black | 120BK009 | N/A | |
| Nordic Oak | 120LS009 | N/A | |
| Reclaimed Split | 120DS004 | N/A | |
| Rosewood | 120RE009 | N/A | |
| Sandblasted Dover | 12081089 | N/A | |
| Sandblasted Warm White | 12002909 | N/A | |
| Warm Oak | 120MS008 | N/A | |
| Warm White | 12002908 | 12502908 | |

^{*} Finish recommended for consumers looking to match the color of their blinds to white window trim.

FAUX WOOD PRODUCT DETAILS

- Our unique NuWood™ material ensures the highest quality at an incredible value.
- NuWood resists warping, cracking, and fading over the full life of the product.
- Available in 2" and 2 1/2" slats.
- Classic Value custom faux wood is offered in six popular finishes.
- · Available in 2" privacy slats.

| Faux Wood Finish Index | | | | |
|--------------------------------|--------------|-------------------------------|---------------|--|
| Finish Name | 2" Faux Wood | 2" Classic Value Faux Wood | 2½" Faux Wood | |
| Aged White | 120WH055 | N/A | 125WH055 | |
| Almost White | 12067100 | N/A | 12567100 | |
| Chenille | 120BE014 | N/A | 125BE014 | |
| Cherry | 120RE007 | N/A | N/A | |
| Colonial Mahogany | 120RE008 | N/A | N/A | |
| Colonial Pine | 12067405 | N/A | N/A | |
| Cool White | 120WH051 | N/A | N/A | |
| Dover | 12067160 | N/A | N/A | |
| Espresso | 120DS007 | N/A | 125DS007 | |
| Golden Oak | 12067217 | N/A | 12567217 | |
| Hickory | 12067410 | N/A | N/A | |
| Light Gray | 120GY046* | GY046 | 125GY046 | |
| Pecan | 120BR036* | BR036 | 125BR036 | |
| Sandblasted Cool White | 120WH052 | N/A | N/A | |
| Sandblasted Dover | 12067371 | N/A | N/A | |
| Sandblasted Warm White | 12067265 | N/A | N/A | |
| Sandblasted White [†] | 120WH054* | WH054 | 125WH054 | |
| Summer Wheat | 120YW007 | N/A | N/A | |
| Walnut | 120BR035* | BR035 | 125BR035 | |
| Warm White | 12067130* | 67130 | N/A | |
| White [†] | 120WH053* | WH053 | 125WH053 | |

^{*}Color available in 2" Classic Value Faux Wood

This tone of white coordinates with the most widely used contractor grade white paint

[†] Finish recommended for consumers looking to match the color of their blinds to white window trim. This tone of white coordinates with the most widely used contractor grade white paint.

OPTIONS AVAILABILITY

| Available Options | | | | | |
|---|--------------|----------------|--------------|----------------|-------------------------------|
| S = Standard Option O = Free Option U = Upgrade N/A = Not Available | | | | | |
| Category | 2" Real Wood | 2 ½" Real Wood | 2" Faux Wood | 2 ½" Faux Wood | 2" Classic Value Faux Wood |
| Cordless | S | S | S | S | S |
| Motorization | U | U | U | U | N/A |
| Privacy Route | U | U | U | U | S |
| Wand Tilt | S | S | S | S | S |
| Traditional Style Package | 0 | 0 | 0 | 0 | N/A |
| Transitional Style Package | 0 | 0 | 0 | 0 | N/A |
| Contemporary Style Package | 0 | 0 | 0 | 0 | N/A |
| Classic Value Style Package | N/A | N/A | N/A | N/A | S |

STANDARD AND FREE OPTIONS

CHOICE OF STYLE PACKAGE

Select from three packages that best fits the style of your room. Style packages include a decorative valance and wand handles.


 $A vailable \ on \ 2" \ and \ 2 \ \frac{1}{2}" \ blinds \ only. \ Choice \ of \ Style \ Package \ not \ available \ on \ Classic \ Value \ Faux \ Wood.$

Traditional – An established look with sharp lines and fine details

Transitional – A symmetric aesthetic with clean, balanced lines

Contemporary – Softened curves and sweeping lines

| Style Packages Available by Price Group | | | | |
|--|-------------|--------------|--------------|---------------|
| S = Standard Option O = Free Option N/A = Not Available | | | | |
| Price Group | Traditional | Transitional | Contemporary | Classic Value |
| A - 2" Classic Value Faux Wood | N/A | N/A | N/A | S |
| B - 2" Faux Wood | 0 | 0 | 0 | N/A |
| C - 2" Faux Wood | 0 | 0 | 0 | N/A |
| D - 2 ½" Faux Wood | 0 | 0 | 0 | N/A |
| E - 2" Real Wood | 0 | 0 | 0 | N/A |
| F - 2 ½" Faux Wood | 0 | 0 | 0 | N/A |
| H - 2" Real Wood | 0 | 0 | 0 | N/A |
| I - 2" Real Wood | 0 | 0 | 0 | N/A |
| J - 2 ½" Real Wood | 0 | 0 | 0 | N/A |



OPTIONS AVAILABILITY

EXTENSION BRACKETS


For installation requiring additional space between the blind and the mounting surface.


Not available on Classic Value Faux Wood.

SPACER BLOCKS

Used to space blind away from mounting surface and avoid obstructions such as window trim, window locks, or on double hung windows.

Each spacer block extends the blind by $\frac{3}{8}$ ". One spacer block per bracket will be provided when requested.





CONTROL OPTIONS AND POSITIONING

Choice of control position is available. Tilt control left is standard position.

WAND TILT


Wand tilt is the default tilt control and standard on cordless blinds. For Classic Value, wand tilt left is the only option.




Wand Tilt

HOLD-DOWN BRACKETS

Hold-down brackets prevent blinds from swaying. They can be sill mounted, face mounted, or mounted inside the frame. Recommended for French doors and windows subject to wind exposure. Must be requested at time of order.





UPGRADES

PRIVACY ROUTE

Edge route design for lift cords provides tighter closure to minimize light for increased privacy and security. Slats can easily be removed for cleaning. Standard on Classic Value Faux Wood.



Privacy Slat



Standard Slat



Cordless



Classic Value Cordless

CORDLESS CONTROL

The design of our cordless operating system creates a clean profile across all of your windows and makes it easy to lift and lower your blinds without dangling cords. The functional LEVOLOR button smoothly raises and lowers your blinds when pressed and locks the blinds in position when released.

MOTORIZATION

LEVOLOR® InMotion™

Experience motorization like never before with smart home integration and automated scheduling.

- Powered by an integrated, rechargeable lithium-ion battery.
- · Recharge with included magnetic micro-USB charger.
- · Control shades with the 15-channel remote (sold separately).
- Add the hub (sold separately) to sync with Wi-Fi to enable app control and smart home integration. Links with Amazon Alexa, Google Home, IFTTT, Samsung SmartThings, and Siri.
- · See real-time shade position and battery charge status.
- Store preset shade positions as scenes. Create routines by scheduling scenes by day of week and time of day.
- Use the app to adjust shades from anywhere.
- · App available to download for iOS and Android devices.
- · Not available with Classic Value Faux Wood



Remote Requires 2 x AAA batteries, included

App Requirements: - LEVOLOR Hub - 2.4 GHz Wi-Fi Network - Apple® iOS 10.0 or newer - Android® 6.0 or newer



Hub Requires 5V 2A adapter, included. Connect up to 30 shades per hub.



App Phone sold separately.

NOTE: LEVOLOR® InMotion™ is not compatible with products from the previous LEVOLOR® motorization program. This includes blinds/shades that are controlled with the previous LEVOLOR app, 3-channel remote, and 6-channel remote.

Visit LEVOLOR.com/InMotion for additional information.

InMotion[™] Accessories Overview

LEVOLOR® INMOTION™ WALL SWITCH

The InMotion Wall Remote lets you achieve effortless light control with the touch of a button, mounted to a wall to avoid misplacement. A great solution for hard to reach windows or in grand rooms with various automated solutions.

- Integrates with the LEVOLOR InMotion App or simply works by itself
- Operates an unlimited number of LEVOLOR motorized window coverings
- Features a clean, modern design with easy to use controls
- Activate group control and favorite position with a touch of a button
- Control up to 15-channels from one remote
- Hide unused channels for faster channel selection and scrolling
- Locking feature to prevent accidental programming changes
- No need to cut in to wall with the wireless design
- Dimensions: 3.4" L x 3.4" W x 0.7" D



LEVOLOR® INMOTION™ SOLAR PANEL

Harness the power of solar energy to power your motorized blinds and shades, ensuring reliable and efficient performance. A great choice for hard to reach windows.

- One Solar Panel per shade or blind is needed
- Easy to install and the low profile design is easy to conceal
- Provides a continuous charge to internal rechargeable batteries
- \bullet Syncs with the LEVOLOR InMotion $^{\text{TM}}$ App to show battery level
- Not recommended on north facing windows
- Micro USB charging cable, 59" long (included)
- Can be added to any existing InMotion ™ blind or shade
- Dimensions: 18.7" L x 2" W x .30" D



OPTIONS AVAILABILITY

MULTIPLE BLINDS ON ONE HEADRAIL

Provides the flexibility of raising one blind while keeping the other lowered. Two or three blinds on one headrail are available up to a total maximum width of 144". Innerspace is ½" between blinds. Horizontal slat alignment not guaranteed.



Not available on Classic Value Faux Wood.

REPLACEMENT VALANCE OPTION

Maximum total valance width is 144". Valances greater than 96" will be spliced.

Classic Value Faux Wood's maximum total valances width is 108" and valances will not be spliced.

MULTIPLE BLINDS ON ONE HEADRAIL HELPFUL NOTES:

- Available up to a total maximum width of 144"
- Each blind operated independently
- There will be inner spacing between slats of individual blinds to operate independently
- Inner spacing between blinds is ½ in.
- Always use a metal tape measure as cloth may stretch
- Take all measurements to the nearest 1/8 in. DO NOT take any deductions
- The factory will make any necessary adjustments to help ensure your blind operates smoothly
- Horizontal slat alignment is not guaranteed

Cleaning and Care

Keep your LEVOLOR Real and Faux Wood blinds looking their best by periodically wiping them with a soft cloth, a duster, or the brush attachment from a vacuum cleaner.

Note: Improper cleaning may void warranty

- You can clean the blind hanging in place or you can take it down.
- By tilting the slats down, but not quite closed, you will be able to clean most of the top surface of each slat.
- Do not use water, solvents, or abrasive solutions to clean the blind. This will cause damage to the blind which is not covered under warranty.
- · Real Wood Blinds: In very dusty environments, you may use a non-wax furniture polish to clean the blind.
- Faux Wood Blinds: You may use a soft, lightly dampened cloth to clean your NuWood blinds.
- Blinds with Privacy Route: Slats can be removed for cleaning. Slide out the slat, wipe clean, and return to its original position. If a light gap occurs for any reason, simply flip the slat over to cover or close the gap.

The following information, listed below, is available online at LEVOLOR.com

- Terms and Conditions
- Order Processing


Freight

- Claims and Returns
- Warning and Safety Information
- Warranty

For additional product information visit LEVOLOR.com/woodblinds

PARTS AND COMPONENTS

| 2" and 2 ½" Real & Faux Wood Blinds | | |
|-------------------------------------|----------------------------------|---------------------|
| | Part Description | Part Number |
| 1 | Installation Brackets | Varies by Color |
| 2 | Center Support Bracket | 1851792 |
| 3 | Extension Bracket - 2" | L01X20000010 |
| 4 | Extension Bracket - 4" | L02X40000010 |
| 5 | Hold Down Brackets – 2" and 2 ½" | DWL01893 / HBHD0004 |
| 8, 9, 10 | Wand Handle | Varies by Color |
| 11 | Wand Sleeve | K11B280000091 |
| 12 | Valance Clip - No Lift | HFCP0002 |
| 6 | Valance Clip - Wand Tilt | 1836002 |
| 7 | Valance Clip - Motorized | 1032944 |
| 13 | 2" Slat Clip | W22T0000 |
| 14 | 2 ½" Slat Clip - Top / Bottom | W14S2500 / 1006500 |
| 15, 16, 17 | Valance Returns | Varies by Color |
| 18 | Cordless Bottom Rail End Cap | Varies by Color |
| 20 | Remote Control Kit (optional) | 1029591 |
| 21 | Motorized Battery Pack | 62203400 |
| 29 | 10' Micro-USB Charging Cable | 62206300 |
| 30 | Power Adapter | 62200000 |
| 31 | 1' Magnetic Charging Adapter | 62206100 |
| 32 | Battery Clip – Motorized | 1032943 |
| 33 | Hub (optional) | 1041770 |
| 34 | Magnetic Insert | 62206200 |
| 35 | Wall Switch | 1039045 |
| 36 | Solar Panel | 62201000 |



PARTS AND COMPONENTS

| 2" Classic Value Faux Wood | | | |
|----------------------------|------------------------|-----------------|--|
| | Part Description | Part Number | |
| 1 | Installation Brackets | Varies by color | |
| 2 | Spacer Blocks | KIT-38BLOCK-2PK | |
| 3 | Center Support Bracket | 1039484 | |
| 4 | Hold Down Brackets | 1039490 | |
| 5 | 24" Wand | Varies by color | |
| 6 | 36" Wand | Varies by color | |
| 7 | 36" Wand - 2 Piece | Varies by color | |
| 8 | Wand Insert | Varies by color | |
| 9 | Valance Clip | 1039293 | |
| 10 | Bottom Rail Endcap | Varies by color | |
| 11 | Valance Returns | Varies by color | |

